



ARCTIC CAT BOLT ON FOR "SPEED RACKS"

If you have any comments, suggestions or questions, please send an email to: info@sawgrip.com

THANK YOU for purchasing SawGrip

You will enjoy the advantages of owning the SawGrip chainsaw carrier for your ATV. SawGrip is made to mount on the front rack. Your chainsaw sets horizontal with the rack.

INSTALLATION:

Remove U Bolts from ATV plate. Place ATV plate over front top rail. Center ATV plate between the welded ends of front top rail. Install U Bolts on each of the rail pipes. (FIG 1). DO NOT tighten U Bolts until all 4 are in place, then tighten each one evenly. **EXCESSIVE tightening will break the U-Bolts.**

SET RESISTANCE:

After Saw Grip is bolted to ATV rack and tightened, open bar clamp up enough so chainsaw bar will go between the rubber pads. Tighten bottom lock nuts leaving about 1/8" or less gap. (Fig. 3) then tighten top T - Handle about the same. Pull on saw. If saw moves easily you may have to tighten bottom and top adjusting nuts and T - Handle until saw has resistance on it. Once the right tension is applied you can put the saw in or out, without always adjusting. If you want a tight fit for traveling just tighten top T-Handle only until saw can't be pulled out. It is recommended to remove saw from The Saw Grip before transporting ATV on trailer or any other means of transport. **Total chainsaw length must not exceed the width of the ATV.**

